



Malibu Dreams

# Malibu Clay

Complexity: **Easy** | Topcoating: **Hard Wax Oil Matte**  
 Brushing: **Optional** | Finish: **Matte**

An earthy look sealed with hard wax oil for style and protection.

Malibu Clay applied on brushed white oak.  
 Results will vary depending on the colour and type of your original wood floor.

Products used
 <p>1x Bona Craft Oil Clay</p>
 <p>1x Bona Hard Wax Oil Matte</p>

Directions	Drying time
1. Prepare the floor and end the sanding with grit 120. Vacuum carefully.	
2. Waterpop the surface by applying a thin coat of water. A sponge or short-haired roller can be used for this. Restrain the amount of water yet make sure to wet all the wood.	12 h
3. Thoroughly stir the oil and apply it to the floor using a stainless-steel trowel, squeegee or white buffing pad (approx. 30 m <sup>2</sup> /lit).	15-30 min
4. After 15-30 minutes, buff the surface with a buffing machine equipped with a red pad.	15-30 min
5. Make another pass with more oil.	
6. After another 15-30 minutes, remove surplus oil using cotton cloths. Allow to dry.	12 h
7. Vacuum surface and apply one coat of Bona Hard Wax Oil Matte using a Bona Microfiber Roller 5 mm (20-24 m <sup>2</sup> /lit). Allow to dry.	12-24 h

#### Other information

- It is recommended to always waterpop prior to oil application to ensure color intensity and uniformity.

This guide describes the overall treatment process of wooden floors and does not replace technical and safety datasheets, that are subject to change, and must be observed prior to use. The drying times suggested are typical drying times at 20°C/60% RH, and must be adjusted to local indoor climate conditions.