


Nordic Shimmer

# Nordic Natural

Complexity: **Easy** | Topcoating: **Traffic Natural**  
 Brushing: **Optional** | Finish: **Natural matte**

For the look and feel of pure wood and a silky, smooth barefoot experience.

*Nordic Natural applied on brushed white oak.  
 Results will vary depending on the colour and type of your original wood floor.*

Products used
 <p><b>2x Bona Natural</b></p>
 <p><b>1x Bona Traffic Natural</b></p>

Directions	Drying time
1. Prepare the floor and end the sanding with grit 120.	
2. Apply Bona Natural using a roller or other suitable applicator following the direction of the wood (approx. 10-12 m <sup>2</sup> /lit).	1-2 h
3. Abrade to reduce grain raise using the Bona Diamond Abrasives grit 120.	
4. Apply a second coat of Bona Natural in the same manner.	2-3h
5. Protect surface with Bona Traffic Natural.	12-24 h
6. An additional coat of lacquer may be needed in high traffic areas.	

#### Other information

- In high traffic areas, consider ending with two layers of Bona Traffic Natural.
- Bona Traffic Natural has a rougher surface than traditional lacquers. For highly trafficked commercial areas, consider replacing with Bona Traffic HD Extra Matt for a similar appearance with easier clean up.

#### Special considerations

Herring bone floors can be challenging to treat with tinted lacquer. Floors that are laid in falling lengths are best suited for this application.

*This guide describes the overall treatment process of wooden floors and does not replace technical and safety datasheets, that are subject to change, and must be observed prior to use. The drying times suggested are typical drying times at 20°C/60% RH, and must be adjusted to local indoor climate conditions.*